

RIZOO Highway Pegs

Designed for select BMW® R1200 Motorcycles

Installation Instructions



RIZOO-Peg Parts List

Qty.	Description
2	RIZOO-Pegs
2	Mounting Brackets
8	7/8" Stainless Steel Bolts
1	3/16" Hex Key (Allen Wrench)

CVM Touring Accessories
www.cvmtouring.com

© COPYRIGHT 2001, 2002, 2003, 2004 CVM TOURING ACCESSORIES ALL RIGHTS RESERVED - All pictures, information, technical specifications, technical designs, and product names are (c) Copyright or Trademark (tm) protected. All Trademarks are property of the respective companies.

••• RIZOO-Pegs are intended for show use only. •••

Install the RIZOO-Peg.

1. Prior to installation, turn key to off position.
2. Remove the spark plug/ignition coil cover from valve cover.
3. Unplug control wire from ignition coil.
4. Unclip and remove control wire/plug keeper.
5. Reconnect the control wire to the ignition coil.
6. Select the correct RIZOO Peg for each side.
When open, the top of each peg will have a machine cut tread.
7. Place the RIZOO Peg into the valve cover in place of the plastic spark plug/ignition coil cover.
8. Slide the RIZOO Peg mounting bracket into the valve cover.
Bracket and peg will not be touching.
9. Using four bolts, attach mounting bracket to the RIZOO Peg.
Thread and tighten bolts evenly to ensure proper peg fit.
10. Repeat for the opposite side.

Maintenance.

1. Periodically check the tightness of the mounting bolts.
The peg must be firmly mounted to the valve cover.
2. RIZOO-Pegs should be washed regularly to remove any abrasive debris.
3. Apply grease to the pivot and detent mechanism regularly. **FAILURE TO DO SO WILL VOID ALL PRODUCT WARRANTIES.**

Be safe! Open or close the RIZOO-Pegs only when the engine is not running. Never adjust accessories when in traffic or when in motion.

For Show Use Only